

<b>Ford (Gold)</b>		
A 000-80001-00		A1 000-80002-00
B 000-80003-00		B1 000-80004-00
C 000-80005-00		C1 000-80006-00
D 000-80007-00		D1 000-80008-00
E 000-80009-00		E1 000-80010-00
G 000-80011-00		G1 000-80012-00
1 000-80000-00		
9 000-80070-00		Also need PushLoc (See below)
97 000-80078-00		98 000-80079-00
<b>Asian &amp; Other Types of Vehicles</b>		
8 000-80036-00		<b>(Requires 2)</b>
<b>Chrysler (Gray)</b>		
H 000-80013-00		H1 000-80014-00
I 000-80015-00		I1 000-80016-00
F 000-80017-00		F1 000-80018-00
V 000-80019-00		V1 000-80020-00
CA 000-80052-00		CA1 000-80053-00
61 000-80054-00		62 000-80055-00
3 000-80021-00		
4 000-80022-00		
<b>Optional Adapters</b>		
95 000 80080 00		96 000 80081 00
2B 000 80107 00		
300 80126 00		Standard with ATX-3 only (dipstick capability required)

<b>General Motors (Silver)</b>		
J 000-80031-00		J1 000-80032-00
K 000-80033-00		K1 000-80034-00
2A 000-80035-00		
27 000-80059-00		28 000-80060-00
29 000-80071-00		30 000-80072-00
23 000-80061-00		24 000-80062-00
21 000-80063-00		22 000-80064-00
25 000-80065-00		
20 000-80073-00		
26 000-80075-00		Use With # 28 Shown Above
		1/4 5/16 3/8 (Qty=2) 1/2
	Clamp (Qty=2 each)	8 - 12 mm 10 - 16 mm 16 - 25 mm
	PushLoc	3/8 5/16
	PushLoc	Ford F150
<b>Optional Adapters</b>		
93 000 80082 00		
94 000 80111 00		
100 000 80112 00		
101 300 80148 00		
91 000 80115 00		
92 000 80116 00		

**GM Vehicles (Silver)**

GM 5/16 in. diameter	All	J & J1
GM 3/8 in. diameter	All	K & K1
GM 7/16 in. Inverted Flare	All	21 & 22
GM 1/2 in. Inverted Flare	All	23 & 24
GM 3/8 in. Quick Connect	1996 or newer	2 & 3/8 in. Female Hose
GM 1/2 in. Quick Connect	Newer SUVs & trucks	25 & 1/2 in. Female Hose
GM 5/8 in. Quick Connect	Pick ups w/ Allison trans	27 & 28
Duramax Diesel	2001 – 2004	29 & 30
Cadillac CTS	2002 – 2003	20 & 3/8 in. Female Hose
GM Allison	2004 - newer	26 & 28
<b>GM</b>		<b>2B</b>
<b>Saturn</b>		<b>95 &amp; 96</b>

**Ford Vehicles (Gold)**

Ford 5/16 in. diameter	1980 & newer	B & B1
Ford 3/8 in. diameter	1985 & newer	A & A1
Ford Quick Connect Fitting	1985 & newer	1 & 5/16 in. Female Hose
Ford Contour & Mystique	1995 & newer	D & D1
Ford Escort	1995 & newer	G & G1
Ford Diesel Truck		E & E1
Ford Aerostar, Jaguar, Mercedes & Cadillac	1985 & newer	C & C1
Ford F150 – Crown Victoria 3/8" quick disc.	2001 – newer	9 (Also Need F150 PushLoc)
Ford F250 – 6.6 liter	2004 – newer	97 & 98
<b>Ford – 1/2" quick disconnect</b>	<b>2007- newer</b>	<b>93</b>
<b>Ford – 1/2" quick disconnect - Mustang</b>	<b>2009 - newer</b>	<b>100</b>
<b>Ford Fusion, Taurus</b>	<b>2010 - 2013</b>	<b>94</b>
<b>Ford Fusion, Taurus</b>	<b>2013 – newer</b>	<b>101</b>

**Chrysler Vehicles (Gray)**

Jeep Cherokee	1980 to 1986	H & H1
Jeep Cherokee, Grand Cherokee With Quick Connect Fitting	1987 & newer	3 & 3/8 in. Female Hose
Jeep Cherokee, Grand Cherokee	1993 & 1994	I & I1
Jeep Cherokee, Grand Cherokee	1998	V & V1
Jeep Grand Cherokee	1995 to 2004	3 & 3/8 in. Female Hose
Jeep Grand Cherokee	2005 & newer	61 & 1/2 in. Female Hose
Jeep Liberty	2002 - 2012	61 & 62
Dodge Durango	1998 - 2009	F & F1
Dodge Ram 1500	1999 & newer	CA & CA1
Dodge Truck V6 & V8	1995 & newer	3 & 3/8 in. Female Hose
Dodge Truck V10 & Diesel	1995 & newer	4 & 1/2 in. Female Hose
Chrysler 300C with Hemi 5.7 Liter Engine	2005 & newer	2A (30 <sup>0</sup> Silver) & 3/8 in. Female Hose
Dodge Truck – 6.6 liter	2004 & newer	97 & 98

**Honda / Acura****91 & 92****Asian & Other Types of Vehicles** Non Color Coded General Purpose Adapters & Gold 8 Adapter.

<b>European – Available as a kit (300 80129 00)</b>		
<b>47C</b> 000-80085-00		
<b>52</b> 000-80089-00		<b>52A</b> 000-80090-00
<b>45</b> 000-80095-00		<b>46</b> 000-80096-00
<b>51</b> 000-80099-00		<b>51A</b> 000-80100-00
<b>53</b> 000-80101-00		<b>53A</b> 000-80102-00
<b>54</b> 000-80103-00		<b>54A</b> 000-80104-00
000-80108-00		
000-80109-00		
<b>Optional Adapters (European)</b>		
<b>47</b> 000-80097-00		<b>48</b> 000-80098-00
<b>55</b> 000-80105-00		<b>55A</b> 000-80106-00
<b>56</b> 000 80117 00		<b>56A</b> 000 80118 00
000-80110 00		

<b>European - Available as a Kit (300-80049-00)</b>		
<b>L</b> 000-80023-00		<b>L1</b> 000-80024-00
<b>M</b> 000-80025-00		<b>M1</b> 000-80026-00
<b>N</b> 000-80027-00		<b>N1</b> 000-80028-00
<b>AV</b> 000-80029-00		<b>AV1</b> 000-80030-00
<b>99</b> 000-80047-00		
<b>VO</b> 000-80049-00		<b>(Requires 2)</b>
<b>35</b> 000-80051-00		<b>(Requires 2)</b>
<b>31A</b> 000-80050-00		
<b>37</b> 000-80056-00		
<b>40</b> 000-80068-00		<b>41</b> 000-80069-00
<b>38</b> 000-80066-00		<b>39</b> 000-80067-00
<b>43</b> 000-80076-00		<b>44</b> 000-80077-00

**European**

Audi	2000 & newer	43 & 44
BMW & Mercedes	1985 & newer	M & M1 or Ford (Gold): G & G1
BMW Flare Adapter	up to 1985	N & N1
BMW O-Ring Adapter	1987 & newer	L & L1
BMW w/ Quick Connect Adapter		37 & 3/8 in. Female Hose
BMW Quick connect 14mm		52 & 52A
BMW Quick connect 14.3mm (5 Series)		53 & 53A
BMW Quick connect 11.7mm (5L4DE Transmission)		000 80109 00
BMW, X5	2007-2009	56/56A
Mercedes Quick connect 13.6m (SL,ML,GL,CLK)	2008 & Newer	54 & 54A
Mercedes Vito Sprinter 9.2mm	2008 & Newer	000 8010800
Volvo, Jaguar, Mercedes Jaguar	1985 to 1992	Ford (Gold): C & C1 47 & 48
Volvo	1992 to 1998	AV & AV1 & 99
Volvo	1996 & newer	31 & 1/2 in. Female Hose
Volvo S40		51/51A
Volkswagen	All Models	VO & 35 (2 of each req'd)
Volkswagen Spin on		68
Volkswagen DSG	2007 & Newer	
Volkswagen / Nissan / Audi (Passat 2.0/2.0T, Jetta 2.5, Audi A4)	2006 & Newer	55 & 55A
Land Rover & Range Rover	1996	40 & 41
Range Rover	1997	38 & 39
Saab	2003-2008	47C

**Adapter Applications shown in red not included in Adapter Set shipped with the ATX.  
Contact MAHLE (800-468-2321 ext. 1) if having difficulty adapting to a particular transmission.**